

Operation, Maintenance and Service Manual

Flyball

Operation, Maintenance and Service Manual

ATARI INC.
14600 WINCHESTER BLVD
LOS GATOS, CA 95030
(408) 374-2440 • TELEX 357-488

By the Publications Group, Engineering Department



Table of Contents

<i>Subject</i>	<i>Page</i>
I. INTRODUCTION	1
1.1 <i>Physical Description of Game</i>	1
1.2 <i>Summary of Game Play</i>	1
II. SPECIFICATIONS	3
2.1 <i>General</i>	3
2.2 <i>Electrical</i>	3
2.3 <i>Environmental</i>	3
2.4 <i>Owner/Operator Options for Structuring of Play</i>	3
2.5 <i>Accessories Available on Separate Order</i>	3
III. THEORY OF OPERATION	5
3.1 <i>Functional Description of Game</i>	5
3.2 <i>General Information</i>	5
3.2.1 <i>Energizing the Game</i>	
3.2.2 <i>TV Monitor</i>	
3.2.3 <i>Picture on TV Screen</i>	
3.3 <i>Game Sequence</i>	7
3.3.1 <i>Operating Modes</i>	
3.3.2 <i>Attract Mode</i>	
3.3.3 <i>Game Sequence in Play Mode</i>	
3.3.4 <i>Owner/Operator Options</i>	
3.4 <i>Detailed Technical Description of Operation</i>	9
3.4.1 <i>General Information</i>	
3.4.2 <i>Sheet 6 of Schematic</i>	
3.4.3 <i>Sheet 1 of Schematic</i>	
3.4.4 <i>Sheet 2 of Schematic</i>	
3.4.5 <i>Sheet 3 of Schematic</i>	
3.4.6 <i>Sheet 4 of Schematic</i>	
3.4.7 <i>Sheet 5 of Schematic</i>	
3.4.8 <i>Sheet 7 of Schematic</i>	

Table of Contents

IV. INSTALLATION INSTRUCTIONS	13
4.1 <i>Unpacking Instructions</i>	13
4.1.1 <i>Examination for Shipping Damage</i>	
4.1.2 <i>Mechanical Inspection</i>	
4.2 <i>Energizing the Game</i>	14
4.2.1 <i>Application of AC Power</i>	
4.2.2 <i>Check on Operation of Interlock Switches</i>	
4.3 <i>Game Structuring</i>	14
4.4 <i>Functional Check of Game Operation</i>	15
4.4.1 <i>Check of Attract Mode</i>	
4.4.2 <i>Check of Play Mode</i>	
V. MAINTENANCE AND ADJUSTMENTS	17
5.1 <i>Routine Maintenance</i>	17
5.1.1 <i>Cleaning</i>	
5.1.2 <i>Lubrication</i>	
5.2 <i>Adjustments on TV Monitor</i>	17
5.3 <i>Adjustment of Speaker Volume</i>	18
5.4 <i>Adjustment of Potentiometers on Joystick Assemblies</i>	18
VI. TROUBLESHOOTING AND REPAIR	23
6.1 <i>General Procedure</i>	23
6.1.1 <i>Identifying the Trouble Area</i>	
6.1.2 <i>Locating the Trouble Cause</i>	
6.1.3 <i>Correcting the Trouble Cause</i>	
6.1.4 <i>Verifying Correct Game Operation</i>	
6.2 <i>Test Equipment</i>	24
6.2.1 <i>Basic Test Equipment</i>	
6.2.2 <i>Optional Test Equipment</i>	
6.3 <i>Specific Troubleshooting Information</i>	26
6.3.1 <i>Coin Mechanism</i>	
6.3.2 <i>TV Monitor</i>	
6.3.3 <i>Joystick-Related Trouble Symptoms</i>	
VII. SCHEMATICS, DRAWINGS, AND PARTS LISTS	29

I. INTRODUCTION

1.1 PHYSICAL DESCRIPTION OF GAME

Atari's "Flyball" is a baseball video action game for two players. The game is packaged in its own distinctively-styled upright cabinet that rests directly on the floor. A 19-inch black-and-white TV monitor is mounted inside the cabinet, with the monitor chassis tilted back in a nearly horizontal position. The two players stand side by side in front of the cabinet, looking down at the picture on the TV screen. (Drawing number A005292 in Section VII of this manual shows external and section views of the cabinet.) The TV screen is surrounded by a bezel upon which a baseball stadium graphics design has been printed. A transparent plexiglass panel is placed in front of the bezel, at a distance of a few inches above the surface of the picture tube.

The player-operated controls are mounted on a panel at the front of the cabinet, between the players and the TV screen. The controls consist of two joystick levers, one for each player, and two push button switches. One switch is backlighted and has the words TWO PLAYER START engraved on the button; the other switch is not backlighted and the words "Press button to hold runner!" are printed on the panel above the button. Instruction diagrams for operating the joysticks are also printed on the panel near each joystick.

Two identical coin mechanisms are mounted on the front of the cabinet, below the player controls. They accept quarters only and are connected so that either one can initiate play. The cash box is located behind a locked access door to the coin mechanisms. A speaker is mounted in the top portion of the cabinet, above the TV screen. During play it produces a variety of sounds that add to the game excitement.

1.2 SUMMARY OF GAME PLAY

A player's objective in "Flyball" is the same as that in a real baseball game—to score more runs than the opponent does. Just as in a real game every ball pitched will turn out to be a strike, a ball, or a hit. Also, an inning lasts until three outs have been made by each side. In Flyball an out is made after three strike pitches are thrown, or else when the

pitcher intercepts a ball in play and then tags a runner heading for a base or for home plate. The players take turns at pitching and batting.

The play sequence starts out with the player at the left being the pitcher. After three outs the left player becomes the batter and the right player becomes the pitcher. By means of an owner/operator option the game can be structured to last for one inning, or else for two innings. Counts of the runs scored by each player are continuously displayed near the top of the TV screen; inning number, and current counts of balls, strikes and outs are displayed near the bottom of the screen.

The video action takes place on a ballfield diamond in the center part of the screen. At the beginning of a play sequence only two ballplayer figures appear: the batter behind home plate and the pitcher in the center of the diamond. The player batting moves his or her joystick lever to change the position of the bat; pushing the joystick forward causes the bat to swing forward and pulling the joystick back causes it to swing back. The player pitching operates his or her joystick to control two types of motion—ball motion, and after a hit the motion of the pitcher figure running about the playfield in pursuit of the ball.

The player batting has the choice of letting a ball go by or of swinging at it. When no swing was made, the game decides whether the pitch was a strike (inside the "strike zone") or else a ball. But if the batter swings and misses, that pitch is counted as a strike. If four pitches have been counted as balls, that batter gets a walk and a new batter will appear. The pitcher can "throw" a new pitch as soon as the previous ball has gone off the screen.

If the batter succeeds in hitting the ball, it reverses direction and goes out onto the diamond. Also the batter figure immediately changes to a running figure that heads toward first base. The player pitching must now manipulate the joystick so that the pitcher moves to intercept the ball and then to tag a runner. Meanwhile the runner automatically continues toward the base. If the base is reached

before the pitcher has caught the ball, then the runner continues on toward the next base. The runner will stop at a base only if the pitcher has already caught the ball or else a player has depressed the "hold runner" push button. Each runner reaching home plate causes a run to be registered, and then the runner disappears.

When the pitcher succeeds in tagging a runner, that runner disappears from the screen and an out is registered. The pitcher figure returns to the pitching position at the center of the diamond after all runners have been put out or else are safe on base. New batters keep appearing until the last out has been made in the last inning, at which point the play sequence ends. The final scores remain showing however.

While pitching, the players quickly discover that more vigorous movement of the joystick lever will cause the pitcher figure to throw faster balls, and that right after the pitch a movement of the joystick

to the right or left adds a corresponding right or left curve to the ball's flight path toward the batter. Likewise while batting the players discover that vigorous movement of the joystick produces faster bat swings and corresponding harder hits, and that direction of ball motion resulting from a hit can be chosen by careful timing of the bat swing. Batters also discover that bunts can be made merely by holding the bat stationary and letting the ball collide with it.

Three types of sounds are produced by the speaker during a play sequence. A crowd roar sound, with three levels of amplitude, is heard continuously during play. A "crack" sound is heard when the bat hits the ball, and a footsteps sound when a runner is advancing toward a base.

Section III of this manual gives additional details about game play and describes the owner/operator options.

II. SPECIFICATIONS

2.1 GENERAL

Cabinet Dimensions: Height 63 $\frac{3}{8}$ in., Width 25 $\frac{1}{4}$ in., Depth 29 $\frac{3}{8}$ in.
TV Monitor: Motorola Model XM501, black and white, with 23-inch screen.
Coin Mechanisms: Two identical mechanisms (connected in parallel); accept quarters only.
Cash Box: Removable; located behind locked access door to coin mechanism assembly.
Power Cord: Approximately 6 ft. long, extending from rear of cabinet and having grounded three-prong plug for conventional wall outlets.

2.2 ELECTRICAL

Power Requirement: Uses conventional wall outlet providing 60-cycle AC (60 Hz, single phase) at 110 volts; rated at about 100 watts.
Fusing: All fuses located inside cabinet; TV monitor has two 1-amp fuses and remainder of game is protected by a 1-amp slow-blow fuse.

Power Interrupt Switch:

This is a safety switch located inside the cabinet. It causes the AC power to the game to be interrupted whenever the rear panel access door is unlocked and opened.

2.3 ENVIRONMENTAL

Operating and Storage from 32°F to 120°F (*Ambient Temperature Range: Temperature*)
Relative Humidity: From 0% to 80% *without condensation*

2.4 OWNER/OPERATOR OPTIONS FOR STRUCTURING OF PLAY

- Cost of a Game Play: can be set for 25¢, 50¢ or \$1 (four coins)
- Game Length: can be set for 1 or for 2 innings
NOTE: A speaker volume adjustment is also provided.

2.5 ACCESSORIES AVAILABLE ON SEPARATE ORDER

Video Probe: order from Atari
Universal Test Fixture: order from Atari, catalog no. TF-101

III. THEORY OF OPERATION

3.1 FUNCTIONAL DESCRIPTION OF GAME

The block diagram in Figure 3-1 shows the major functional parts of the Flyball game and their interconnections. Note that the game printed circuit board sends a composite video signal to the TV monitor and a separate audio signal to the speaker.

3.2 GENERAL INFORMATION

The general information about the Flyball game given here provides a background for understanding the Installation Instructions in Section IV of this manual, and the description of game operation in paragraphs 3.3 and 3.4.

3.2.1 Energizing the Game:

The game does not have an external "Power On" switch. Instead it is energized as soon as the power cord is plugged into an active AC wall outlet. This outlet must provide the AC power listed in the Specifications (Section II of this manual).

3.2.2 TV Monitor:

The game's TV monitor is a self-contained transistorized television monitor supplied to Atari by Motorola. Because the composite video signal sent to the monitor by the game control circuitry differs in certain important respects from the signal derived from commercial TV broadcasts, the picture appearing on the screen is unlike that of a home TV set and the monitor does not produce any sound.

3.2.3 Picture on TV Screen:

The game's composite video signal is constructed to produce only two video levels (white and black), instead of the more or less continuous shades of gray seen on a home TV screen. Figure 3-2 shows a typical picture that would appear on the screen during play and identifies the objects in the picture.

The ball and the pitcher are allowed to move about on the playfield. But the bat swing motion always occurs at home plate, and the runners are only allowed to run forwards (counterclockwise) along the baselines. The remaining objects are held in stationary positions on the TV screen.

3.3 GAME SEQUENCE

3.3.1 Operating Modes:

During use the "Flyball" game can be described as operating in either of two modes, attract or play. Plugging the power cord into an active AC outlet energizes the game and it starts out in the attract mode. The game remains in the attract mode until a player deposits a coin and the coin clears the coin mechanism, at which point a signal derived from the coin mechanism causes the game to go into the play mode. The game remains in the play mode until the third out is made during the last half of the last inning. At that point the game reverts back to the attract mode.

For certain servicing purposes only the game can be made to operate in a third "diagnostic" mode. Subparagraph 6.3.3 in Section VI of this manual gives guidelines about when to put the game in this mode.

3.3.2 Attract Mode:

Figure 3-3 shows a typical picture that would appear on the TV screen after completion of a play sequence in the play mode. After initial application of AC power the picture in the attract mode may vary somewhat from that shown in the figure.

The words *GAME OVER* near the top of the screen will be blinking on and off at a rapid rate. The words in the entire top line of writing will be changed approximately every one or two seconds, with the following sequence being repeated over and over again:

"PITCHER CHASE BALL TAG RUNNER"
then "MOVE CONTROL ⬆ TO PITCH OR BAT"
then "MOVE CONTROL ⬅ TO MOVE PITCHER"
and then "25 CENTS PER GAME." The words about game cost will correspond to the cost choice set up by an owner/operator option, so that the specific words appearing will be one of the following: "25 CENTS PER GAME," or "50 CENTS PER GAME," or "4 COINS PER GAME."

In the attract mode one runner figure will be rapidly advancing around all the bases, and past home plate, over and over again. The pitcher figure




Figure 3-1 Functional Block Diagram of Flyball Game




Figure 3-2 Typical Picture During Play




Figure 3-3 Typical Picture During Attract Mode

will remain motionless in the center of the playfield diamond. Neither a batter figure nor a ball will appear. No runs are registered during the attract mode; instead the scores left over from the most recent play sequence will remain showing throughout the attract mode. None of the other numerical information (counts of strikes, balls, outs, and inning number) will change either.

3.3.3 Play Mode:

Players cause the game to change over from the attract mode to the play mode by depositing coins in

the game. After a coin has been accepted, the game will respond by changing the second line on the picture, as follows. The words GAME OVER will disappear and a "coins accepted" announcement will appear (such as ONE COIN ACCEPTED, TWO COINS ACCEPTED, etc.). When the number of coins deposited reaches the amount needed for a game play, the game will respond by lighting up the START pushbutton. To continue the play sequence, a player must now depress the START pushbutton. At this point in the play sequence the game will also recognize a player's depressing of the unlighted

side-by-side switches. Each switch can be set either in an "on" or an "off" position. One combination of settings will fix the cost at 25¢ per game play; a second combination will fix it at 50¢, and a third will fix it at \$1 (four coins).

(b) *Game Length Option.* This option consists of another switch on the same switch assembly. Setting this switch in one position fixes the game length at 1 inning, and setting it in the other position fixes it at 2 innings.

3.4 DETAILED TECHNICAL DESCRIPTION OF OPERATION

3.4.1 General Comments:

This subsection gives a technical description of the game's electronic circuitry. Drawing number 005629 is a nine-sheet schematic diagram of the circuitry on the printed circuit board, and drawing number A005629 is the PCB assembly drawing showing the locations of the components called out on the schematic. The position of each integrated circuit device is identified by a column letter designation (A through R), and by a row number designation (1 through 9). Drawing number 005816 is a schematic of the harness wiring inside the game cabinet. These drawings and a schematic diagram of the TV monitor's circuitry are included in Section VII of this manual.

On the PCB schematic the symbol *P* (appearing at various inputs to logic gates and other integrated circuits) indicates a connection to + 5 volts through a pull-up resistor.

In the subparagraphs that follow, the portions of the circuitry being described can be located on the PCB schematic by finding the intersection of the zone letters (A, B, C or D) and the zone numbers (1 through 8). For example, the designation *Sheet 1, Zone A 8* refers to the extreme lower left corner of sheet 1 of the schematic.

Sheet 9 of the PCB schematic is a detailed block diagram of the board's circuitry. The main data and control interconnections between the blocks, as well as those coming from the front panel joysticks and switches, are also shown on the diagram.

This subsection of the manual gives technical descriptions of game circuitry regarded as field-repairable. Correction in the field of problems

traced to certain portions of the circuitry on the game's PCB may require replacement of the entire board.

3.4.2 Sheet 6 of Schematic:

(a) *Clock Generator (Zone D7 & D8).* The output of a 12-MHz crystal-controlled oscillator drives flip-flop L1 to produce the H CLOCK signal at L1 pin 5. This signal provides the basic clock synchronization for the game circuitry and also drives the horizontal countdown chain.

(b) *Horizontal and Vertical Countdown Chains (Remainder of Sheet).* Flip-flop L1 and counters R1 and P1 form a countdown chain that counts down the frequency of the H CLOCK signal to produce the 1H through 256H timing signals. Certain of these signals are applied to flip-flop N2 to produce the H SYNC signal whose timing forms the basis for the horizontal synchronization information sent to the TV monitor on the composite video signal.

The H SYNC signal is also applied to counters A3 and B3 and flip-flop D2 and N2, which form the vertical countdown chain. These counters produce the 1V through 128V timing signals. Also flip-flop N2 produces the \overline{VRESET} signal that changes state once per picture frame. Counter R8 (in Zone B2) produces a signal whose timing forms the basis for the vertical synchronization information sent to the TV monitor.

(c) *Video Summing (Zone C2).* The junction of resistors R44 through R48 forms the video summing point for the various signals that are combined on the composite video sent to the TV monitor. The timing of the PLAYFIELD signal, coupled through R45, determines when a picture is produced on the TV screen. The synchronization information is coupled through R46. The ball portion of the TV picture is coupled through R47, the pitcher figure through R48, and the remaining playfield objects through R44.

3.4.3 Sheet 1 of Schematic:

(a) *Joystick Interface (Zones B, C, D 7 and 8).* The eight potentiometers on the PCB are adjusted at the factory and *none* of the settings should be disturbed after the game arrives at the game site. (*Only* potentiometers on the joystick assemblies should be adjusted at the game site.) A wire from each joystick potentiometer connects to the negative input of a type-LM339 amplifier.

(b) *Ramp Generator (Zones A 6, 7, 8).* Flip-flop P7 drives a 2N3643 transistor that has a large

resistor-capacitor load connected to its collector terminal. The timing of the flip-flop's output causes a ramp-shaped waveform to appear at the positive inputs to the LM339 amplifiers in location L8. Five ramps are developed during one picture frame time on the TV monitor.

(c) *Pot-Ramp Comparators (Zones B6, C6, D6).* The amplifiers in L8 form four position-sensing circuits, as follows: vertical (up/down) and horizontal (right/left) circuits for the right player's joystick position, and a similar pair for the left player's joystick position. The output of each LM339 amplifier will be either low or high. The output changes from low to high at the time that the ramp waveform crosses the voltage that is applied from the joysticks (at L8 pins 6, 4, 10 and 8). Note that each of the four comparators can change state independently of one another.

(d) *Pot Interrupt Disables (Zones B5, C5, D5) and Pot Interrupt (Zone C4).* At the beginning of a ramp waveform the gates L7 will be open, so that the comparator outputs can pass through the gates and on to gate K6. If any of the signals applied to gate K6 go low, then the output at K6 pin 6 will go high. This signal, along with the ramp timing signal and H SYNC, is applied to gate P2. With this arrangement the IRQ (interrupt request) signal, at gate P2 pin 12, can only be produced during H SYNC time once every line on the TV. Therefore the first comparator to indicate that the ramp has crossed the voltage will be the one to cause the first interrupt to be produced.

(e) *Interrupt Event Time Data (Zones D4 and B4).* When the game's control circuitry receives the interrupt request signal, a READS POTS command is sent to pin 1 of the type-8T98 tri-state buffer in location L6. When a low is applied at pin 1, all four of the gates in the 8T98 will be energized. The D0 through D3 outputs are then interrogated to determine which comparator has caused the interrupt.

After this has been done, the control circuitry shuts off the READS POTS signal and a READ VERT (read vertical) command is produced. A low is applied to pins 1 and 15 of the type-8T97 buffer device in location A4. Now the six timing signals 1V through 32V are passed through and on to the D0 through D5 output lines. This timing allows the control circuitry to determine when the interrupt occurred.

As the last step in the interrogation sequence the control circuitry must close gate L7 to block off the appropriate comparator(s). This is done by means of the D0 through D3 commands which cause the flip-flops in location K7 to be set, thus shutting off gates L7 (at pins 2, or 5, or 12, or 9). All the flip-flops are reset before the start of each new ramp waveform.

3.4.4 Sheet 2 of Schematic:

(a) *X-Y Coordinate Generators (left half of schematic).* For the ball, the counters K4 and D4 produce the horizontal component of its position on the screen, and J4 and E4 produce the vertical component. Likewise, for the pitcher figure, counters L4 and C4 produce the horizontal component of the figure's position, and H4 and F4 produce the vertical component. These are four sets of divide-by-256 counters that are preset at a particular time during the play sequence. The preset information is contained on the eight signal lines $\overline{D0}$ through $\overline{D7}$, and the presetting is done during vertical blanking time.

The ball contribution to the picture is contained in the BALL VIDEO signal produced at P8 pin 12. The outputs from the counters for the pitcher figure connect to two PROM devices in locations E2 and F2, and to a type-74175 device in location F3.

(b) *Graphics Select and Video Shift Register (right half of schematic).* The type-74175 device in location F3 determines which of the pitcher pictures will be selected out of the PROMs. The PROMs have 16 pictures, all for the pitcher only. The type-75166 devices in locations E1 and H1 form a serial shift register. The parallel input data to this shift register come from the PROMs. The shift register is bidirectional; it can shift left or shift right. The output from the shift register produces the pitcher contribution to the TV picture, at P8 pin 10.

3.4.5 Sheet 3 of Schematic:

(a) *Playfield Rams (left half of sheet).* The type-2111 RAMs in locations L3, P3, M3 and N3 produce graphics address data that are applied to the playfield ROM or ROMs shown on sheet 4. The address data applied to the RAMs, in turn, are produced by the two type-74157 devices in locations R3 and K3. The RAMs produce addresses for 512 picture "blocks" (each 8 dots wide by 16 dots high) on the TV screen. But the actual graphics (letters, numerals, baselines, runner figures, etc.), however, are stored in the playfield ROM.

(b) *Video Shift Register (right half of sheet)*. The type-74194 devices form a bidirectional shift register. The outputs from the playfield ROM or ROMs are applied in parallel to this shift register. The playfield objects picture information in serialized form is contained in the VIDEO OUT signal, produced at N7 pin 8. The PLAYFIELD signal contains the timing that determines when the picture will appear on the TV screen.

3.4.6 Sheet 4 of Schematic:

Playfield ROMs (left half of sheet) and Playfield ROM (right half of sheet). The page's printed circuit board is designed so that either *four* ROM devices—in locations J2, L2, K2 and M2—or else *one* type-4600 ROM device can be installed on the board. (A board will be built with one choice or the other, but not both choices simultaneously.) The operation of the game is the same under either choice. The ROM circuit function has already been covered in subparagraph 3.4.5.

3.4.7 Sheet 5 of Schematic:

(a) *Buffers For On-Board Mode Switches and Front Panel Switches (Zone C & D 6, 7, 8)*. The switches contained in the structuring switch assembly mounted on the game's PCB, the switches on the front panel that are operated by the players, and the two coin mechanism switches all connect to the type-8T97 buffer devices in locations K8 and H8. These buffers produce the buffered data, the signals D0 through D7.

(b) *Game Address Decode (right half of sheet)*. The type-7442 devices in locations H3 and M6 are used as decoders that produce the various control signals needed during a play sequence. The type-9334 device in location F7 is used as an addressable latch that produces the control signals used in the sound generation circuitry. This latch also produces a signal that turns on an SCR to provide the lamp current when the TWO PLAYER START push button is to be backlit.

3.4.8 Sheet 7 of Schematic:

(a) *Random Noise Generator (Zones D7 through 8)*. The type-74164 devices in locations B7 and C7, and flip-flop D7 and gates E7, form a digital noise generator. Clocking for this circuit is provided by

the 128V and 256H timing signals produced by the countdown chains (see (b) of subparagraph 3.4.2). The noise output signal is produced at D7 pin 8.

(b) *Bat Sound (Zones C7 & C8)*. The type-556 device in location E8 forms a circuit that produces two short, gated square waves. These signals are slightly offset in frequency, and interact together during the sound summing to give a sharp cracking sound when the ball hits the bat. The circuit is triggered by the BAT HIT ON/OFF signal.

(c) *Crowd Roar (Zone C5)*. The type-LM741 amplifier in location D8 is connected as a bandpass filter. It takes the output signal from the random noise generator and makes it seem more like a crowd roar sound.

(d) *Footstep Generator (Zone B4)*. The amplifier in location C8 acts as a current-controlled volume control circuit. Its output gets louder as the resistance from C8 pin 2 to ground is lowered. The circuit is driven by the FOOTSTEP OFF/ON signal, so that footstep sounds are produced whenever any runner is advancing toward a base or home plate.

(e) *Crowd Volume Control (Zones C3 & C4)*. The amplifier in location A8 also acts a current-controlled volume control. The three control signals CROWD VERY LOUD, CROWD OFF/ON and CROWD SOFT LOUD vary the resistance from A8 pin 2 to ground, so that the three amplitude levels of the crowd roar sound are heard during a play sequence.

(f) *Master Volume Control and Output Amplifier (Zones A through D 1 & 2)*. Potentiometer R95 is connected to the sound summing point and provides the speaker volume adjustment described in paragraph 5.3 in Section V of this manual. The output amplifier drives the speaker mounted in the upper portion of the cabinet, above the TV monitor.

(g) *Power Supply (Zones A, B6 through 8)*. The amplifier is connected in a full-wave diode rectifier circuit that provides the +5 volt supply for the board. A second pair of diodes is connected in a full-wave circuit that produces an unregulated +18 volts for the speaker amplifier circuit.

IV. INSTALLATION INSTRUCTIONS

4.1 UNPACKING INSTRUCTIONS

4.1.1 Examination for Shipping Damage:

Before shipment from the factory, components and sub-assemblies of each game are carefully checked for proper operation. However, during shipment some adjustments may have changed or parts may have been damaged. Upon initial removal of the game from the shipping container, first examine the exterior of the cabinet. Then open the rear (or side) access panel and also examine the interior. Any shipping damage such as a dented, cracked or broken cabinet, sub-assemblies broken loose, etc., should be reported immediately to the shipper and to Atari, Inc.

4.1.2 Mechanical Inspection:

After determining that the game has been received in good condition, carefully inspect the interior parts and verify the following:

- (a) All slip-on and plug-in connectors are firmly seated (particularly the PCB edge connector)
- (b) The fuses are all seated in their holders
- (c) No loose foreign objects are present (especially metal objects which could cause electrical short circuits)
- (d) No harness wires have become disconnected or pulled loose.

Be sure *all* major assemblies have been checked: game PCB, the transformer and other components on the electronics tray assembly, the two coin mechanisms, the speaker, the player controls (joystick levers and push button switches), and the TV monitor chassis.

Do not go on to the remaining paragraphs in this section until the above mechanical inspection has been thoroughly performed.




Figure 4-1 Approximate Locations of Game Structuring Switches and Speaker Volume Adjustment

4.2 ENERGIZING THE GAME

4.2.1 Application of AC Power:

Close and lock the access panel, making sure that it is completely shut at the bottom, and remove the key from the lock. Then plug the power cord into an AC outlet providing the AC power listed in the Specifications (Section II of this manual). The wall outlet must accept a three-prong plug and the receptacle must be connected to a good earth ground.

After the power cord has been plugged in, the proper response from the game is that a picture appears on the TV screen.

If there is no response at all from the game, unplug the power cord and check the AC wall outlet. A simple, safe way to check for presence of AC power at the wall outlet is to plug in an appliance known to be working properly—such as a table lamp, radio, or an electric clock. If the wall outlet passes the check, then presume that the trouble is with the game and refer to Section VI of this manual.

CAUTION

No troubleshooting steps should be attempted inside the cabinet by anyone not familiar with safety measures and repair procedures on electrical equipment.

Do not go on to the remaining paragraphs in this section until the proper response described above has been observed.

4.2.2 Check on Operation of Interlock Switch:

The interlock switch is a safety switch mounted inside the game cabinet near the top edge of the rear access panel. At the factory this switch is mechanically adjusted so that it will automatically transfer to its "off" position (switch contacts "open") whenever the panel is opened. When the interlock switch is in its "off" position, the AC power leading to the game's power supply is interrupted. When the panel is closed, the interrupt switch is adjusted to be in the "on" position (switch contacts "closed") and AC power is allowed to reach the game's power supply, meaning that the game can operate.

After application of AC power per paragraph 4.2.1 above, correct operation of the interlock switch can be checked as follows: unlock and slowly

open the panel. The correct response is that by the time the edge of the panel has moved about 2 to 3 inches away from the cabinet the TV screen should go dark, verifying that the interlock switch has automatically transferred to "off." While opening the panel do not insert fingers inside the cabinet and do not allow foreign objects to fall inside. If the TV screen continues to be lighted up even after the panel has been opened, immediately close and lock it and unplug the power cord from the wall outlet. Then refer to Section VI of this manual to replace and/or adjust the interlock switch.

Do not go on to the remaining paragraphs in this section until the operation of all interlock switches has been checked and found to be correct.

4.3 GAME STRUCTURING

Before putting the game into operation at the game site, the game structuring should be defined by the owner/operator. The term "game structuring" refers to the game rules and the duration of the play sequence. Paragraph 3.3.4 of Section III in this manual covers the owner/operator options featured in this game and describes how they affect the game structuring.

In the Flyball game all structuring is accomplished by selecting positions on a miniature switch assembly mounted on the game printed circuit board. To do this the board has to be removed from its metal enclosure and then the switch positions have to be adjusted by hand.

Before performing any adjustment, the game should be de-energized or not operating. Further, it is also recommended that the power cord be unplugged beforehand.

Unlock and open the rear panel access door; doing this should cause the interlock switch to de-energize the game, as described in paragraph 4.2.2. If the switch fails to de-energize the game, immediately close and lock the door, unplug the power cord, and refer to Section VI of this manual to adjust and/or replace the switch.

While being careful to avoid touching any parts of the body against the TV chassis components or other wiring connections inside the cabinet, find the metal enclosure that houses the game PCB. Then unplug the edge connector to the RF board on the front of the enclosure, carefully noting how the connector plugs in. (It must be reconnected *in*

exactly the same way after the switch positions have been changed.) Next remove the screws holding the RF board onto the enclosure and unplug the RF board from the game PCB. Now the game PCB has been freed so that it can be slid out of the enclosure far enough to allow access to the switches. Examine the surface of the board and identify the switch assembly shown in Figure 4-1. (Its exact location is shown on the PCB assembly drawing, drawing number A005629 in Section VII of this manual, with the designation SW1; the volume adjustment potentiometer is designated R95.) Each of the various two-position switches on the switch assembly can be independently set to either an "on" or "off" position. Table 4-1 lists correct settings for the three choices of game cost, and for game lengths of 1 inning and 2 innings.

Switch #1 }
 Switch #2 } Not used (can be in any position)
 Switch #3 } Game Length is 1 inning when in "off" position; 2 innings when in "on" position.

	Game Cost		
	25¢/game	50¢/game	4 coins/game
Switch #4	on	on	off
Switch #5	on	off	off
Switch #6	Not used; must be left in "off" position for normal game play.		

Table 4-1 Settings on Game Structuring Switch Assembly

After the desired structuring has been set up, slide the game PCB back into its enclosure and plug the RF board back on to the game PCB. Replace the RF board on the front of the enclosure and secure it in place. Then replug the edge connector back onto the RF board, *making sure* that it is reconnected in the way originally found.

After performing these adjustments, close and lock the side panel, and energize the game.

4.4 FUNCTIONAL CHECK OF GAME OPERATION

The following procedure provides a simple check that can be quickly performed at the game site

and that does not require external test equipment. If at any point during this procedure the game's response is found to be other than that called for herein, assume the game is not operating correctly and refer to Section VI of this manual. If responses are as described here then assume that major parts of the game are operating correctly. First perform the adjustments described in paragraph 4.3, Game Structuring, and then energize the game (paragraph 4.2). Just after application of power a picture should appear on the TV screen and the game should be operating in the attract mode as per subparagraph 3.3.2.

NOTE

Sometimes upon initial application of power (or, more rarely, later on during play) the TV monitor may produce a "scrambled" picture. This irregularity happens if the game's internal circuitry has not initialized itself. Although normally taken care of automatically, it is possible that severe noise spikes on the AC power line could upset the self-initialization. Generally a "scrambled" picture can be corrected by de-energizing the game and then re-energizing it, one or more times. Do this either by unplugging the power plug from the wall outlet and reconnecting it, or else by opening and then closing the cabinet's rear access panel so that the interlock safety switch is exercised.

4.4.1 Check of Attract Mode:

No sounds should be produced during the attract mode. The picture should resemble the one shown in Figure 3-3.

As described in subparagraph 3.3.2, the words *GAME OVER* should be blinking on and off, the words in the entire top line of writing should change every one or two seconds, and one runner figure should be advancing around the bases, over and over again. The backlighted TWO PLAYER START push button should be dark. The joystick lever and push button player controls should all be disabled.

4.4.2 Check of Play Mode:

After correct game operation in the attract mode has been verified, deposit a coin in one of the coin mechanisms. As soon as the coin has been accepted, the game should respond by changing over

to the attract mode, as described in subparagraph 3.3.3. If the game cost is set up for 25¢ per game, then the deposit of this first coin will cause the TWO PLAYER START push button to light up. But if the game is set up for 50¢ per game, then a second coin must be deposited. And if set up for four coins per game, then three more coins must be deposited before the start button will light. No sounds should yet be produced by the game speaker.

Depress the backlighted start button. Doing this should cause the picture on the TV screen to change. As described in subparagraph 3.3.3, both scores should be reset to zero, the number "1" should appear after the word INNING, and the count of strikes, balls and outs should all be zero. Also the word PITCHER with an arrow beneath it should be blinking on and off in the lower left corner of the screen, as should the word BATTER with an arrow beneath it in the lower right corner.

Now operate the right-hand joystick and confirm that the batter figure moves the bat through 8 separate positions. The rear-most position of the bat should correspond to the rear-most position of the joystick lever, and the forward-most position of the bat to the forward-most position of the joystick lever. Next operate the left-hand joystick to cause the pitcher figure to throw a ball. After the ball is in motion, operate the left joystick lever to cause the ball to curve to the right and to the left. Next operate the batter joystick so that the batter hits the ball. Confirm that the batter changes to a runner figure that advances toward first base. Next operate the left joystick to confirm that the pitcher figure can be made to chase the ball, catch the ball, and tag a runner so that an out will be registered.

After the first out has been registered, the word BATTER with an arrow beneath it should appear in the lower left corner and be blinking on and off, and the word PITCHER with an arrow beneath it in the lower right corner, also blinking on and off. Continue operating the two joystick levers so that a hit will be made and runs will be scored for each of the players, and confirm that these runs are registered at the top of the TV screen. Continue until all the outs have been made so that the game sequence ends. While doing this also confirm that all the game sounds are being produced, as described in subparagraph 3.3.3.

After the third out in the last inning has been made, the game should change over from the play mode to the attract mode. When in attract no sounds should be produced and the scores should still be showing from the just-completed play sequence.

As the final part of the check deposit one or more coins in the other coin mechanism and confirm that the game changes over to play mode. Go through another play sequence and confirm that depressing the "hold runner" push button will start the sequence and also will cause the runner to hold on base during play. Confirm that depressing the start button will also cause the runner to hold on base.

If at any time during the above check it was found that either joystick lever will not cause the pitcher to throw a ball, or if either joystick lever will not produce at least 7 separate bat positions, then refer to subparagraph 6.3.3 in Section VI of this manual.

This completes the functional check.

V. MAINTENANCE AND ADJUSTMENTS

5.1 ROUTINE MAINTENANCE

Due to its solid-state electronic circuitry, this Atari game should require very little maintenance and only occasional adjustment.

5.1.1 Cleaning:

Game cabinets and glass may be cleaned with any non-abrasive household cleaner. If desired, special coin machine cleaners which leave no residue can be obtained from distributors.

5.1.2 Lubrication:

About once every three months lightly spray the rejector linkage portion of the coin acceptor inside each coin mechanism. Use WD-40® or similar lubricant, and *avoid* spraying the entire coin acceptor. Potentiometer shafts must *never* be lubricated in any way.

5.2 ADJUSTMENTS ON TV MONITOR

The TV monitor need be adjusted *only* when the picture is distorted, or if the contrast or brightness seem out of adjustment.

NOTE

The TV monitor is accessible only from inside the game cabinet and these adjustments have to be done while the game is energized. Therefore only persons familiar with safety measures and repair procedures on electrical equipment should perform them.

The monitor's adjustments function like those of a conventional commercial television set, except that the volume adjustment has no effect. Instead the game produces its sound in a speaker separate from the TV monitor. Figure 5-1 shows the location




Figure 5-1 Location of Adjustments on TV Chassis

of the adjustments on the rear of the chassis. When making the adjustments follow these general guidelines:

- BRITE (Brightness)**—Perform this adjustment before the contrast. Adjust so that the white lines covering the screen just barely disappear, when the brightness is turned up.
- CONT (Contrast)**—Adjust so that the images are as bright as possible against the dark background without being blurred.
- HORIZ HOLD (Horizontal Hold)**—Adjust if the picture is slightly off-center horizontally, if the images appear warped, or if the picture is broken up into a series of diagonal lines. Adjust for a stable, centered picture.
- VERT HOLD (Vertical Hold)**—This needs adjustment only if the picture appears to be rolling up or down the screen. Adjust for a stable, centered picture.

5.3 ADJUSTMENT OF SPEAKER VOLUME

The speaker electronic drive circuit is provided with a potentiometer that controls the volume of sounds produced during play. This potentiometer is mounted on a printed circuit board inside the game cabinet and it can be manually adjusted to give the volume level desired. The following procedure tells how to make this adjustment.

Unlock and remove the access panel at the rear of the cabinet. Doing this should cause the interlock switch to de-energize the game, as described in subparagraph 4.2.2. If the switch fails to de-energize the game, immediately replace and lock the panel, unplug the power cord, and refer to Section VI of this manual to adjust and/or replace the switch.

While being careful to avoid touching any parts of the body against the TV chassis components or other wiring connections inside the cabinet, find the metal enclosure that houses the game PCB. Unplug the edge connector that connects the wire harness to the RF board mounted on the front of the metal enclosure. Note how this connector plugs in; it must be reconnected in *exactly* the same way after the volume adjustment has been made. Next remove the screws that hold the RF board onto the front of the metal enclosure, and then unplug the RF board from the game PCB. The game PCB is now free to move out of the enclosure.

Slide the PCB on its guides until it is partway out and the volume adjustment potentiometer is accessible. Figure 4-1 shows its approximate location.

(Its exact location is shown as R95 on drawing number A005629 in Section VII of this manual.) To increase speaker volume, move the stud on top of the potentiometer body in the direction shown by the arrow in Figure 4-1. To decrease speaker volume, move the stud in the opposite direction.

After making the adjustment, push the game PCB all the way back into the enclosure, replug the RF board onto the game PCB, and then secure it in place on the front of the enclosure. Next replug the wire harness edge connector back onto the RF board, *making sure* that it is reconnected in the way originally found. Then replace the cabinet panel and energize the game.

5.4 ADJUSTMENT OF POTENTIOMETERS ON JOYSTICK ASSEMBLIES

This paragraph gives a procedure for adjustment of the arms on a pair of potentiometers located on each joystick assembly. This adjustment can be done at the game site. At the factory, all potentiometers are initially adjusted and normally will not require any readjustment afterwards. However, if certain trouble symptoms develop, such as those described in subparagraph 6.3.3 in Section VI of this manual, performing this procedure may correct the troubles. If not, shop servicing of the game will be required. The procedure is divided up into four sets of steps that must be performed in the sequence listed.

PRELIMINARY STEPS

- 1) Unlock and open the coin door. DE-ENERGIZE the game.
- 2) Reach inside the cabinet and locate the four bolts that attach the player control panel to the cabinet. Loosen and remove all four nuts from these bolts.
- 3) Carefully lift off the control panel so that the joystick assemblies are visible, and allow the panel to hang by its wires. Take care not to damage the wiring connections or the components mounted on the panel. Now ENERGIZE the game again.
- 4) Locate the "Pot-Set" switch that is mounted just inside the coin door opening, near the door hinge. (When the control panel is removed, this switch can be seen on the front panel, to the left of the coin door, facing the cabinet.) Pull the stud, which protrudes from the "Pot-Set" switch, all the way out. Doing this will put the game in the "diagnostic" mode of operation.
- 5) Now four sets of 2-digit numbers that change with joystick motion will appear along the top of

the TV screen (see Figure 5-2). These numbers can range from 00 through 77, but certain numbers will be skipped. Specifically, there are no 8s or 9s. DO NOT WORRY, BECAUSE THIS IS NORMAL.

VERTICAL ADJUSTMENT STEPS

After the preliminary steps have been performed, these steps should be carried out on the left joystick and then repeated for the right joystick. These steps are a check on the joystick's vertical range. During each step observe the pair of numbers on the screen that correspond to that joystick's movement, as indicated in Figure 5-2.

- 6) When the joystick lever is pushed forward, the minimum number on the screen should be 03 or smaller. This number should be reached at the very end of control motion. That is, after the minimum number is reached, no more control motion should be remaining. If the foregoing is not true, then during game play the pitcher may not be able to pitch his ball.
- 7) When the joystick lever is pulled all the way back, the maximum number on the screen should be reached. This number should be between 63 and 73. If the foregoing is not true, then during play the pitcher will not be able to run down-screen as fast as he should.
- 8) When the joystick lever is left in the spring-center, neutral position, the number showing on the screen should be in the high 30s or low 40s. If the foregoing is not true, then during play the pitcher will run faster in one direction than in the other.
- 9) If misadjustments are found during steps 6, 7, and 8 above, then the appropriate joystick potentiometer must be adjusted. Figure 5-3 shows the general locations of the adjustment points, and Figure 5-4 shows a detail view. Locate and slightly loosen the screws for the control pot in question. Then slowly move the adjusting arm and set it so that you can achieve the correct test results, as described in steps 6, 7, and 8.

During adjustment, the *most* important thing to accomplish is to set the minimum achievable number *equal to or less than 3*, without leftover control motion, as described in step 6. If the numbers called out in steps 7 and 8 also cannot be achieved, the game is probably playable but should be shop aligned at a later date.

However, if game play is unacceptable, then shop realignment is required.

- 10) After the adjustments have been made, retighten the screws on the control pots; tighten just enough to allow finger adjustment of the control-adjusting arm.

HORIZONTAL ADJUSTMENT STEPS

After the vertical adjustment steps have been performed, a similar set of horizontal steps should be carried out on each joystick. During these steps the side-to-side (left to right) motion of the joystick levers will be checked.

- 11) When the joystick lever is moved to the left, the minimum number on the screen should be 10 or smaller. This number should occur at the very left end of joystick motion. That is, after the minimum number is reached, no lever motion should be remaining. When the joystick lever is moved to the right, the maximum number should be 70 or larger, at the very right end of motion. If either of the foregoing is not true, then during play the pitcher's horizontal ball-chasing speed will not be accurately set, or left and right players may run differently.
- 12) When the lever is in the spring-centered, neutral position, the number should be in the high 30s or low 40s. If the foregoing is not true, then during play it may be difficult to make straight-line pitches.
- 13) If misadjustments are found during steps 11 and 12, then the appropriate joystick potentiometer must be adjusted. Locate and slightly loosen the screws for those control pots. Then again move the adjusting arm to achieve the correct test results as described in steps 11 and 12.

During adjustment, the *most* important thing is to spring-center the control and get the numbers close to 37 or 40 on the TV screen, as described in Step 12. If the numbers called out in Step 11 cannot also be achieved, the game is probably playable, but should be aligned at a later date. If game play is unacceptable, then shop realignment is required.

CONCLUDING STEPS

After all the above steps have been carried out, the satisfactory game operation during a normal play sequence should be verified before replacing the control panel.

- 14) Push in the stud that projects from the "Pot-Set" switch; doing this should change the game over from "Diagnostic" mode to attract mode. Then deposit coins to change the game over to play mode.
- 15) Depress the start button and then operate both joysticks to confirm that the correct responses are obtained from the pitcher, ball and the batter. Be sure that each joystick is checked both when it controls the batter and also when it controls the pitcher and ball. If one or more responses are incorrect go back and repeat the appropriate steps from 4 through 13 at least once. Then repeat steps 14 and 15. Now DE-ENERGIZE the game.
- 16) Put the control panel back into its normal position. Put the four nuts back on their respective bolts and tighten them, so that the panel is held firmly in place.
- 17) Make sure the stud on the "Pot-Set" switch is pushed in, so that the game will be taken out of "diagnostic" mode.
- 18) Close and lock the coin door. Then turn on the power again. This completes all steps in the procedure.




Figure 5-2 Picture on TV Screen During Diagnostic Mode




Figure 5-3 Locations of Adjustments on Rear Side of Control Panel




Figure 5-4 Detail View of Joystick Assembly

VI. TROUBLESHOOTING AND REPAIR

6.1 GENERAL PROCEDURE

NOTE

*This section describes troubleshooting procedures in detail sufficient for a person with moderate technical ability to understand. However, for those interested in gaining more information on video game technology, especially the electronics, we recommend reading the **Video Game Operator's Handbook**, manual no. TM-043. This book is available from Atari, Inc., attn. Customer Service Dept., 2175 Martin Avenue, Santa Clara, CA 95050 for \$5.00 each, or from your distributor.*

6.1.1 Identifying the Trouble Area:

The first troubleshooting step should be to note all observable trouble symptoms. Examples of symptoms are: depositing a coin produces no game response, no sound coming out of the speaker at any time, no picture on the TV screen. At the same time also not the game features that still work. A systematic way of checking game operation is to perform the functional check given in Section IV of this manual. Carefully train your eye to pick up all clues; by doing this an experienced troubleshooter can often spot the cause of a trouble even before he opens the cabinet.

Keeping these observations in mind, use the understanding of game operation gained from the theory of operation (Section III) and the schematic drawings (Section VII). Next narrow down the suspected cause of the trouble to a specific area or areas of the game: coin mechanism, TV monitor, harness or front panel components (switches, joysticks, lamps, speaker), electronics tray, printed circuit board or power cord. Be careful not to overlook possible trouble areas that may seem too obvious: a power cord plug that has worked loose from the wall outlet and is no longer fully seated in the receptacle, or a rear panel access door that is not fully closed (thus causing the interrupt switch to block the AC power path to the game).

6.1.2 Locating the Trouble Cause:

Once a problem has been narrowed down to one or more areas, the next step is to perform various tests and measurements to isolate a specific cause of the trouble. Remember that sometimes a very complicated problem, such as erratic game operation, can be traced to a simple cause—the printed circuit board not being fully seated in its edge connector. Start with the most suspect area and trace backwards from the point where the trouble is first observable, using a process of elimination to eventually locate the faulty component, connection, etc. For example, if no sound is audible during game play, first check for a signal at the speaker leads. If no signal is present there, go back through the wiring harness connections to the printed circuit board. If there is still no signal, then systematically check back through the various components of the sound generation circuit.

Substitution of parts is a legitimate and easy way to isolate the cause. For instance, if the PCB is the suspected trouble area, remove it and substitute a known-to-be-good PCB. Then check for correct game operation. Similarly, to check the TV monitor, connect the game to a known-to-be-good monitor. The harness can often be checked by substitution also. Substitute both a known-to-be-good PCB and TV monitor. If the trouble still persists, the harness must be at fault.

While locating the trouble cause, use the technical descriptions in Section III as guides for correct circuit-level operation, and the schematic drawings of Section VII as roadmaps for tracing signal flow paths.

The test equipment for use in troubleshooting is discussed in paragraph 6.2.

6.1.3 Correcting the Trouble Cause:

In practice, the steps required to correct troubles can range from simple adjustments (fully seating the PCB in its edge connector, changing the setting on a potentiometer, adjusting the picture controls on the TV monitor) to repair of loose connections and replacement of defective parts. Extreme care should be exercised when removing integrated

circuit devices and discrete components. Use a 40-watt soldering iron with a small tip designed especially for IC work. To remove an IC device, follow this procedure:

Clip all leads and lift the IC package out, leaving two rows of leads. Then remove leads individually with a soldering iron and needle-nose pliers. Finally, evacuate the holes with a solder sucker. Afterwards clean the area thoroughly, using an approved PCB cleaning solution to remove any traces of flux and dirt. Alcohol will do in a pinch, if necessary.

Insert the new IC device using an IC insertion tool, making sure that the reference notch is oriented correctly and that the device's leads are not bent during insertion into the board. Afterwards, be sure to solder each lead on *both* sides of the PCB, using as little solder as possible. After soldering, clean the area thoroughly to remove the flux.

Observe the same removal and insertion procedures when replacing discrete components. Trim the leads as close as possible and be sure to orient diodes and capacitors correctly.

6.1.4 Verifying Correct Game Operation:

After locating and correcting the cause of a trouble, re-energize the game and perform a final check on correct game operation. Doing this will verify that your troubleshooting was correct. If the game operation is still not correct, go back and double-check your work. Make sure that any replaced components were installed correctly. If this was done properly, then start the troubleshooting steps over again. Keep in mind that there may be more than one trouble at a time, and that correcting one trouble can sometimes bring previously undetectable troubles to light.

This verification is especially important when the original trouble had been intermittent, that is, was not happening all the time.

6.2 TEST EQUIPMENT

Electronic troubleshooting of a video game essentially consists of checking for the presence of various signals and of examining their condition. A signal can be thought of as acting like a "messenger" that carries instructions from one unit or circuit to another. Many different types of signals are produced in a video game, and for this reason several unusual and perhaps unfamiliar types of test

instruments are used during troubleshooting. Each instrument has its own set of advantages and disadvantages for examining a given type of signal, and both the depth of the intended troubleshooting capability and budget will determine what instruments will be needed. Some instruments are basic and essential, no matter what size of service facility, while other optional instruments are desirable because they make troubleshooting easier and quicker.

6.2.1 Basic Test Equipment:

(a) *The Video Probe.* This is a simple but invaluable instrument having two leads—a test-clip lead and a test-probe lead. During troubleshooting of video signals the test-clip lead is left connected to the game side of the video coupling capacitor. On the Flyball game this point is the junction of resistors R44 through R48 on the PCB. When the test-probe lead is then connected to any video developmental signal, that signal will be coupled to the video signal going to the TV monitor and a video probe picture will appear on the TV screen. The shape and other characteristics of this picture will give information about the signal being probed. The video probe is suited for troubleshooting synchronization and image signals, but will not be useful for extremely fast signals (such as the clock) or for very slow analog or digital signals.

A video probe can be constructed in a few minutes from these common electrical components: a length of 20 AWG (American Wire Gauge) rubber-coated wire, a 4.7K-ohm, ¼-watt carbon resistor, and two test leads. For the leads, use a single Mouser test clip (Mouser #131C301 or 302) attached to one end of the wire, and a test prod containing the resistor on the other.

To assemble the video probe, proceed as follows: Remove the cap from the test clip and strip 3/16 inch off each end of the wire. Solder one end to the post in the test clip, thread the other end through the hole in the cap, and snap on the cap. Next unscrew the plastic body of the test prod from the point and trim both leads of the resistor to a 3/16-inch length. Solder one resistor lead to the inside of the point. Thread the other end of the wire through the hole in the body and solder it to the other resistor lead; screw the body back onto the point.

(b) *The Logic Probe.* This is a test instrument designed for fast verification of digital IC outputs. It

is small, convenient to carry, easy to read, and relatively inexpensive. The logic probe derives its power from the system under test; it has two power leads, one for connection to ground and the other to +5 volts DC. When the logic probe's tip is held against a digital signal point, three colored lamps in the tip will indicate the signal's condition or state, as follows:

- The red lamp lit indicates a high or logic level 1 (for TTL components, this is +2.4 to +5 volts)
- The white lamp lit indicates a low or logic level 0 (for TTL components, this is 0 to +0.8 volt)
- The blue lamp lit indicates that the signal is changing states
- No lamps lit indicate the grey region between 0 and 1 (for TTL this is between +0.8 and +2.4 volts)

A circuit shorted to ground will illuminate the white lamp and an open circuit will illuminate the red lamp.

The logic probe is readily available from electronic supply sources; a commercial model found satisfactory is the Kurz-Kasch model LP 520.

(c) *The Logic Pulser*. This test instrument is similar in size and shape to the logic probe, and it also derives its power from the system under test. When the logic pulser's tip is held against a digital signal point, the source and sink capabilities of the pulser override any IC output and the point is driven to the opposite logic level. If the point that the logic pulser is held against is low, pressing the switch on the side of the pulser will introduce a high pulse. Conversely, pulsing a high line will pull that line low momentarily.

During troubleshooting the logic pulser allows stimulation of in-circuit ICs with a shaped digital pulse. For example, a certain feature of the game may not be working and you suspect that a circuit is not receiving the necessary signal. Use the pulser to imitate that signal: if the circuit begins working, you have proved that the signal was in fact missing and you can begin tracking it down. This technique is very similar to jumping coils in electromechanical games such as pinball machines.

In addition to the regular "pulse" button, there is another switch mounted on the logic pulser. When this switch is set in the "rep" mode, the instrument pulses the digital signal point at a 5-Hz rate or 5 times per second. This extremely low rate is

slow enough to allow watching events initiated by the pulser. Counter outputs, for example, are more easily observed when the counter is pulsed or clocked at this rate.

The logic pulser is also readily available from electronic supply sources; a commercial model found satisfactory is the Kurz-Kasch model HL 583.

(d) *Oscilloscope*. The most versatile test instrument, and also the most expensive, is the oscilloscope. The high-speed TTL integrated circuits used in video games produce fast-rise-time signals. The oscilloscope should have a 50-MHz bandwidth, dual trace and dual time base capability. These latter features allow examination of both input and output signals simultaneously, so that precise timing relationships can be checked. The oscilloscope should also have provision for internal or external sync.

Of the newer, solid-state oscilloscopes, a satisfactory model is the Tektronix 465.

(e) *VOM or Volt-Ohmmeter*. This common measuring instrument is extremely useful in video game troubleshooting. It can be used to check line voltage, transformer secondary windings, continuity, resistance, power supply voltages, and to some extent used for measurements in the analog circuitry.

One commercial model found satisfactory is the Simpson 260.

6.2.2 Optional Test Equipment:

(a) *The Logic Comparator*. This test instrument's main benefit is that it can be used to check the functioning of an integrated circuit device while the device is still in place on the printed circuit board. The logic comparator performs the check by comparing the suspect ICs functioning with that of an identical-type reference IC mounted in the instrument itself. Suppose that the functioning of a type-74193 device on the PCB is suspected to be defective. First insert a program card with a known-to-be-good 74193 into the logic comparator, and then clip the comparator test leads onto the leads of the suspect device. If there are any logic state differences between the reference IC and the suspect IC under test, then an LED on the logic comparator will light up to indicate which output is not functioning correctly. Once a defective IC has been located, it should be replaced.

Logic comparators are readily available from electronic supply sources.

(b) *Atari Universal Test Fixture.* In situations where a large number of video games are being serviced, investment in the Universal Test Fixture will be justified. This item of test equipment forms a test station for troubleshooting printed circuit boards after they have been removed from the game cabinet. The Universal Test Fixture has a full set of controls for operating the game and also has its own TV monitor. The game's PCB is plugged into an edge connector mounted on the side of the Fixture; with this arrangement the PCB is positioned in a convenient way for connecting probes and other test instruments.

A program card inserted into a receptacle in the top of Fixture takes the place of the game's interconnect wires. The program card thus sets up the Fixture for each particular game; the game's name is clearly printed on the program card itself.

With the Universal Test Fixture the method of troubleshooting via substitution of known-to-be-good parts is made fast and convenient. For example, suppose that the TV picture in a game is completely broken up and you want to determine whether the game or monitor is causing the problem. Remove the PCB and plug it into the Fixture's edge connector, and also insert the correct program card for that game. If the picture on the Fixture's monitor is correct, then you know that the problem lies in the game's monitor.

6.3 SPECIFIC TROUBLESHOOTING INFORMATION

The following subparagraphs give additional troubleshooting information about certain areas of the Flyball game.

6.3.1 Coin Mechanism:

If a player inserts a coin and the game does not respond, first check the coin mechanism. If pressing the coin rejector button forces the rejector mechanism to return the coin, then examine the coin to make sure that it is genuine. If it is, then use a set of your own test coins (which should include both very new and very old, worn coins) to determine whether or not the player's coin is undersize or underweight. If your test coins are also returned, this indicates that servicing of the coin acceptor portion of the coin mechanism is called for. Generally the cause of this particular problem is an improperly adjusted magnet gate.

Inside the coin mechanism a magnet is used to test the metallic composition of the coin. Highly magnetic coins, such as those made of steel or iron, will be retained by the magnet and can be returned by actuating the wiper operating lever. Coins having comparatively high magnetic properties will be slowed down by the magnet, and will drop off the end of the rail short of the "accept" entrance and be returned. Coins having little or no magnetic properties, such as brass or zinc coins, will pass through the magnetic field so fast that they will overshoot the "accept" entrance and be returned.

A magnetic gate adjusted with too large a gap may pass both genuine and counterfeit coins. An adjustment with too small a gap can lead to rejection of some or even all coins. Over a period of time, the screw that adjusts the magnet gate has a tendency to work loose, resulting in a gradual narrowing of the gate. At first, only the thickest (i.e., newest) coins are rejected. As time passes, more and more coins are rejected until finally player complaints lead to the calling of the game repairman.

If pressing the coin rejector button does not cause the coin to be returned, and if the game still does not respond, then check the coin mechanism to see if the coin is jammed inside.

If you are certain that the coin is genuine, and that the coin passes through the coin mechanism and into the cash box, then the lack of game response is probably due to some kind of electrical trouble. Check for signals at the electrical contacts of the coin mechanism before moving on to the harness and other parts of the circuitry.

6.3.2 TV Monitor:

The TV monitor is a self-contained unit housed in its own chassis. A trouble's cause may be narrowed down to the monitor—either by the substitution method using a known-to-be-good monitor, or by verifying presence of AC power to the monitor power supply and presence of the *correct* composite video signal. The entire monitor can then be removed from the game cabinet. Doing this facilitates troubleshooting steps, because all monitor components will then be accessible.

A schematic diagram of the monitor circuitry is included in Section VII of this manual. After disconnecting and removing the monitor from the game, standard TV troubleshooting techniques are adequate for locating causes of trouble. Additional

servicing information is available from the monitor manufacturer (Motorola).

6.3.3 Joystick-Related Trouble Symptoms:

This subparagraph describes certain trouble symptoms that may be traced to the joysticks and their potentiometers. Some of these troubles can be corrected at the game site by performing the potentiometer adjustments described in Paragraph 5.4 in Section V of this manual. Correction of the remaining troubles will require shop servicing.

(a) Symptom: When one or both joysticks are operated the pitcher figure cannot be made to pitch a ball; i.e., the ball never leaves the pitcher's hands. Or else it takes several tries to pitch properly.

Trouble Cause: Probably the vertical motion pots on the joystick assemblies will not reach the minimum, as described in the adjustment procedure of Paragraph 5.4.

(b) Symptom: Pitcher can be made to chase ball, but seems to run faster in one direction than the other.

Trouble Cause: Joystick pots probably not centered. Adjust centering, but be sure that the low numbers mentioned in Paragraph 5.4 are still obtainable.

(c) Symptom: Pitcher will not run as fast as he should, or left and right player speeds are much different.

Trouble Cause: Joystick pots probably not centered, or may require shop re-alignment.

(d) Symptom: Batter has fewer than 7 bat positions on screen.

Trouble Cause: Probably misadjustment of joystick pots. May require shop re-alignment.

(e) Symptom: Game does not play; four pairs of numerals appear at top of screen and they vary with joystick position.

Trouble Cause: Game has been put in the "diagnostic" mode. To correct this trouble make sure that Switch #6 of the miniature switch assembly on the printed circuit board is put in the "off" position, *and* that the "Pot-Set" switch is in its "contacts open" position with stud pushed all the way in. (Paragraph 5.4 describes the location of the "Pot-Set" switch.)

VII. SCHEMATICS, DRAWINGS AND PARTS LISTS

Number	Title
A005292	Parts List and Drawing Top Assembly
005824	Drawing Screened Control Panel
A005429	Parts List and Drawing Control Panel Assembly
A005820-01	Parts List and Drawing Electronics Tray Assembly
005816	Schematic Harness
A005629	Schematic, Parts List and Drawing Printed Circuit Board
(none)	Schematic Motorola Model XM501/701 TV Monitor

BASEBALL



ASSEMBLY TITLE / BASEBALL TOP ASSEMBLY

P/L A005292

PARTS LIST SPECIFICATION

Page 1 of 1

Drawn

Checked

Mech. Eng

Proj. Eng.


Elec. Eng

REV.

C

Rev.	Description	Date	Apprv.	Rev.	Description	Date	Apprv.
A	PROD REL	6-10-76					
B	Rev per ECN 2766	6-22-76					
C	Rev per ECN 2802	6-30-76					


Item	Part Number	Qty.	DESCRIPTION
1	A005291-02	1	Cabinet Assembly, (Silkscreened)
2	A005430	1	Display Assembly
3	A005427	1	Monitor Support Assembly
4	A005820-01	1	Electronics Tray Assembly
5	A005912-01	1	R.F. Shield Assembly
6	A005429	1	Control Panel Assembly
7	A003637-08	1	Coin Door Assembly
8	005378-01	1	Shield Monitor (Silkscreened)
8A	005699-01	Ref	Shield, Monitor
9	A 005380	1	Bezel, Cardboard
10	71-2114	1	Lock, Mech., Barrel Cartridge
11	68-001	2	Interlock Switch, A.C. Power
12	000268	2	Interlock Switch Bracket
13	005419	1	Speaker Grill (8" Speaker)
14	005422	1	Shield, Display Light (Silkscreened)
14A	005843-01	Ref	(Breakout) Light Box Plex Panel
15	003053	2	Upper Plex Retainer, (Anti-Aircraft)
16	75-99090006	6	Weldnut, #10-32
17	73-77002	4	Pop Rivet, 3/16" O.D. x 3/4" Lg.
18	75-5524B	4	Carriage Bolt, # $\frac{1}{4}$ " - 20 x 1- $\frac{1}{2}$ " Lg. Black
19	75-015S	4	Washer, Flat, # $\frac{1}{4}$ "
20	75-045	4	Washer, Split-Lock, # $\frac{1}{4}$ "
21	75-915S	4	Nut, Hex, # $\frac{1}{4}$ " - 20
22	72-6012	4	Screw, S.M., Pan Hd., Phil., #10 x 3/4" Lg.
23	75-010S	6	Washer, Flat, #10
24	75-040	10	Washer, Split-Lock, #10
25	75-911S	6	Nut, Hex Hd., #10-24
26	75-5120B	6	Carriage Bolt, #10-24 x 1- $\frac{1}{4}$ " Lg. Black
27	72-6812	4	Screw, S.M., Pan Hd., Phil., #8 x 3/4" Lg.
28	72-6608	5	Screw, S.M., Pan Hd., Phil., #6 x $\frac{1}{2}$ " Lg.
29	82-8014B	6	Button Head Screw, #10-32 x 7/8" Lg.
30	005817	Ref	Harness Schematic
31	A005629	1	P.C. Board (Flyball)
32	A005490-01	1	R.F. Board (Flyball)
33	72-6608	10	Screw, S.M., Pan Hd., #6 x .50" Lg.



REV	DATE	BY	CHKD	APPROVED
B	10/1/78	J. L. B.	J. L. B.	J. L. B.
B PRODUCTION RELEASE				
C REV PER ECU 2802				

ATARI INCORPORATED	
1000 BAYVIEW BLVD.	
REDWOOD CITY, CALIF. 94061	
DRAWING NO. P/L C05292	TITLE TOP ASSEMBLY FLYBALL
DATE 10/1/78	DESIGNED BY J. L. B.
CHECKED BY J. L. B.	APPROVED BY J. L. B.
SCALE 4:50%	SHEET NO. 1 OF 2

NOTES: UNLESS OTHERWISE SPECIFIED



1 2 3 4

REVISION		
ZONE	SYM	DESCRIPTION
A		PRODUCTION REL
		DATE 6/76

D C B A

DRAWING NO.	005824
SHEET	1
REV	A

ATARI INCORPORATED
10100 N. GARDEN ST.
LOS GATOS, CALIFORNIA 95030

TITLE	
CONTROL PANEL (SCREENED)	
DATE	5-25-76
DRAWN BY	ENGINEER
CHECKED	ENGINEER
PROJECT ENGINEER	
W/C ENGINEER	

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON:	DO NOT SCALE DRAWING
ANGLES .10	DATE 5-25-76
SURFACE FINISH .010	

MATERIAL	MAKE FROM
005360-01	
FINISH	SEE NOTE


005429	FLYBALL
NEXT ASSY	USED ON
APPLICATION	

NOTES: UNLESS OTHERWISE SPECIFIED

SCALE	1
SHEET	1
OF	2

ATARI

BASEBALL



ASSEMBLY TITLE / CONTROL PANEL ASSY

P/L A005429

PARTS LIST SPECIFICATION

Page 1 of 1

Drawn

Checked

Mech. Eng.

Proj. Eng.

2


Elec. Eng.

REV.

A

Rev.	Description	Date	Apprv.	Rev.	Description	Date	Apprv.
A	PROD REL	6-11-76					

Item	Part Number	Qty.	DESCRIPTION
1	005824	1	Control Panel, w/Graphics
1A	005360-01	Ref	Panel, Control
2	A004304-11	1	Double Light Switch Assembly - Blank
3	A004304-10	1	Double Light Switch Assembly - 2 Player
4	71-6103	2	Joystick Assy (EK- Logictrol)
5	A005818	1	Control Panel Harness



REV	DATE	DESCRIPTION
1	6-25	PROD. REL


DRAWING NO. A005429
 SHEET 1
 REV A

DO NOT SCALE DRAWING DESIGNED BY CHECKED BY DATE 6-10-76	TITLE CONTROL PANEL ASSY
SEE 005429 MATERIAL P/L 005429	PARTS / NUMBER M/C 1000000 /

A005429 1/2 7 BALL NEW PART USED ON VARIATION	DRAWING NO. A005429 SHEET 1 REV A
--	---

1 INCLUDE IN THE ASSEMBLY ON ITEM #4
 NOTES UNLESS OTHERWISE SPECIFIED

FLYBALL



ASSEMBLY TITLE

ELECTRONICS TRAY ASSY

P/L A005820-01

PARTS LIST SPECIFICATION

Page 1 of 1

Drawn

Checked

Proj. Eng.

Mech. Eng



Elec. Eng

REV.

A

Rev.	Description	Date	Apprv.	Rev.	Description	Date	Apprv.
A	PROD RFI	6/17/76					

Item	Part Number	Qty.	DESCRIPTION
1	005289-01	1	Electronics Tray
2	A005817-01	1	Main Harness
3	A005817-02	1	Interlock Switch Harness
4	001551-01	1	Transformer, 001551
5	005497-03	1	Cover Transformer
6	000871-01	1	Label
7	46-201202	1	Fuse, 2 AMP
8	79-3201	1	Fuse Holder
9	41-2001	1	Filter, 2 AMP Power Line
10	A004576-03	1	AC Power Cord, 8 Ft Assy
11	A001921-01	A/R	Shorting Block, 95V
12	A001921-02	"	" " 110V
13	A001921-03	"	" " 220V H
14	A001921-04	"	" " 220V L
15	72-6608	1	Screw, SM, Pan Hd Phil #6 x 1/2 Lg
16	72-6612	7	" " " " #6 x 3/4 Lg
17	72-6812	7	" " " " #8 x 3/4 Lg
18	A005817-03	1	Flyball Jumper Assy



TRANSFORMER WIRE COLORS


CURRENT VERSION -01

ATARI INCORPORATED 14600 Wilshire Blvd. Los Gatos, California 95030	
ATARI	
TITLE: FLYBALL ELECTRONICS TRAY ASSEMBLY	
SIZE: C	DRAWING NO: A005820
SCALE: 1:2	SHEET: 1 OF 1
DO NOT SCALE DRAWING	
DRAWN BY:	DATE:
CHECKED:	ENGINEER:
PROJECT ENGINEER:	
WRT. ENGINEER:	
MATERIAL:	
FINISH:	
NEXT ASSY:	
USED ON:	
APPLICATION:	


NOTES: UNLESS OTHERWISE SPECIFIED

REVISIONS				
ZONE	SYM	DESCRIPTION	DATE	APPROVED
	A	PROD REL	6/77	


DRAWING NO	SHEET	REV
A005820	V1	A



REVISIONS				
SYM	DESCRIPTION	INITIALS and DATE		
		DRAFT	CHECK	ENGR
A	PRODUCTION RELEASE			




NOTES: UNLESS OTHERWISE SPECIFIED:
1. RESISTANCE VALUES ARE IN OHMS.
2. CAPACITANCE VALUES ARE IN MICROFARADS.





CURRENT VERSION -01
EXTERNAL INPUTS

APPLICATION	
FLYBALL	
NEXT ASSY	USED ON


INTERPRET THIS DRAWING PER USAS VIALS		DRAWN BY		DATE	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON:		CHECKED		3-9-76	
FRACTIONS = 1/16 3/32 1/8 1/4 3/8 1/2 5/8 3/4 7/8 1 1 1/4 1 1/2 1 3/4 2 2 1/4 2 1/2 3 3 1/4 3 1/2 4 4 1/4 4 1/2 5 5 1/4 5 1/2 6 6 1/4 6 1/2 7 7 1/4 7 1/2 8 8 1/4 8 1/2 9 9 1/4 9 1/2 10 10 1/4 10 1/2 11 11 1/4 11 1/2 12 12 1/4 12 1/2 13 13 1/4 13 1/2 14 14 1/4 14 1/2 15 15 1/4 15 1/2 16 16 1/4 16 1/2 17 17 1/4 17 1/2 18 18 1/4 18 1/2 19 19 1/4 19 1/2 20 20 1/4 20 1/2 21 21 1/4 21 1/2 22 22 1/4 22 1/2 23 23 1/4 23 1/2 24 24 1/4 24 1/2 25 25 1/4 25 1/2 26 26 1/4 26 1/2 27 27 1/4 27 1/2 28 28 1/4 28 1/2 29 29 1/4 29 1/2 30 30 1/4 30 1/2 31 31 1/4 31 1/2 32 32 1/4 32 1/2 33 33 1/4 33 1/2 34 34 1/4 34 1/2 35 35 1/4 35 1/2 36 36 1/4 36 1/2 37 37 1/4 37 1/2 38 38 1/4 38 1/2 39 39 1/4 39 1/2 40 40 1/4 40 1/2 41 41 1/4 41 1/2 42 42 1/4 42 1/2 43 43 1/4 43 1/2 44 44 1/4 44 1/2 45 45 1/4 45 1/2 46 46 1/4 46 1/2 47 47 1/4 47 1/2 48 48 1/4 48 1/2 49 49 1/4 49 1/2 50 50 1/4 50 1/2 51 51 1/4 51 1/2 52 52 1/4 52 1/2 53 53 1/4 53 1/2 54 54 1/4 54 1/2 55 55 1/4 55 1/2 56 56 1/4 56 1/2 57 57 1/4 57 1/2 58 58 1/4 58 1/2 59 59 1/4 59 1/2 60 60 1/4 60 1/2 61 61 1/4 61 1/2 62 62 1/4 62 1/2 63 63 1/4 63 1/2 64 64 1/4 64 1/2 65 65 1/4 65 1/2 66 66 1/4 66 1/2 67 67 1/4 67 1/2 68 68 1/4 68 1/2 69 69 1/4 69 1/2 70 70 1/4 70 1/2 71 71 1/4 71 1/2 72 72 1/4 72 1/2 73 73 1/4 73 1/2 74 74 1/4 74 1/2 75 75 1/4 75 1/2 76 76 1/4 76 1/2 77 77 1/4 77 1/2 78 78 1/4 78 1/2 79 79 1/4 79 1/2 80 80 1/4 80 1/2 81 81 1/4 81 1/2 82 82 1/4 82 1/2 83 83 1/4 83 1/2 84 84 1/4 84 1/2 85 85 1/4 85 1/2 86 86 1/4 86 1/2 87 87 1/4 87 1/2 88 88 1/4 88 1/2 89 89 1/4 89 1/2 90 90 1/4 90 1/2 91 91 1/4 91 1/2 92 92 1/4 92 1/2 93 93 1/4 93 1/2 94 94 1/4 94 1/2 95 95 1/4 95 1/2 96 96 1/4 96 1/2 97 97 1/4 97 1/2 98 98 1/4 98 1/2 99 99 1/4 99 1/2 100 100 1/4 100 1/2 101 101 1/4 101 1/2 102 102 1/4 102 1/2 103 103 1/4 103 1/2 104 104 1/4 104 1/2 105 105 1/4 105 1/2 106 106 1/4 106 1/2 107 107 1/4 107 1/2 108 108 1/4 108 1/2 109 109 1/4 109 1/2 110 110 1/4 110 1/2 111 111 1/4 111 1/2 112 112 1/4 112 1/2 113 113 1/4 113 1/2 114 114 1/4 114 1/2 115 115 1/4 115 1/2 116 116 1/4 116 1/2 117 117 1/4 117 1/2 118 118 1/4 118 1/2 119 119 1/4 119 1/2 120 120 1/4 120 1/2 121 121 1/4 121 1/2 122 122 1/4 122 1/2 123 123 1/4 123 1/2 124 124 1/4 124 1/2 125 125 1/4 125 1/2 126 126 1/4 126 1/2 127 127 1/4 127 1/2 128 128 1/4 128 1/2 129 129 1/4 129 1/2 130 130 1/4 130 1/2 131 131 1/4 131 1/2 132 132 1/4 132 1/2 133 133 1/4 133 1/2 134 134 1/4 134 1/2 135 135 1/4 135 1/2 136 136 1/4 136 1/2 137 137 1/4 137 1/2 138 138 1/4 138 1/2 139 139 1/4 139 1/2 140 140 1/4 140 1/2 141 141 1/4 141 1/2 142 142 1/4 142 1/2 143 143 1/4 143 1/2 144 144 1/4 144 1/2 145 145 1/4 145 1/2 146 146 1/4 146 1/2 147 147 1/4 147 1/2 148 148 1/4 148 1/2 149 149 1/4 149 1/2 150 150 1/4 150 1/2 151 151 1/4 151 1/2 152 152 1/4 152 1/2 153 153 1/4 153 1/2 154 154 1/4 154 1/2 155 155 1/4 155 1/2 156 156 1/4 156 1/2 157 157 1/4 157 1/2 158 158 1/4 158 1/2 159 159 1/4 159 1/2 160 160 1/4 160 1/2 161 161 1/4 161 1/2 162 162 1/4 162 1/2 163 163 1/4 163 1/2 164 164 1/4 164 1/2 165 165 1/4 165 1/2 166 166 1/4 166 1/2 167 167 1/4 167 1/2 168 168 1/4 168 1/2 169 169 1/4 169 1/2 170 170 1/4 170 1/2 171 171 1/4 171 1/2 172 172 1/4 172 1/2 173 173 1/4 173 1/2 174 174 1/4 174 1/2 175 175 1/4 175 1/2 176 176 1/4 176 1/2 177 177 1/4 177 1/2 178 178 1/4 178 1/2 179 179 1/4 179 1/2 180 180 1/4 180 1/2 181 181 1/4 181 1/2 182 182 1/4 182 1/2 183 183 1/4 183 1/2 184 184 1/4 184 1/2 185 185 1/4 185 1/2 186 186 1/4 186 1/2 187 187 1/4 187 1/2 188 188 1/4 188 1/2 189 189 1/4 189 1/2 190 190 1/4 190 1/2 191 191 1/4 191 1/2 192 192 1/4 192 1/2 193 193 1/4 193 1/2 194 194 1/4 194 1/2 195 195 1/4 195 1/2 196 196 1/4 196 1/2 197 197 1/4 197 1/2 198 198 1/4 198 1/2 199 199 1/4 199 1/2 200 200 1/4 200 1/2 201 201 1/4 201 1/2 202 202 1/4 202 1/2 203 203 1/4 203 1/2 204 204 1/4 204 1/2 205 205 1/4 205 1/2 206 206 1/4 206 1/2 207 207 1/4 207 1/2 208 208 1/4 208 1/2 209 209 1/4 209 1/2 210 210 1/4 210 1/2 211 211 1/4 211 1/2 212 212 1/4 212 1/2 213 213 1/4 213 1/2 214 214 1/4 214 1/2 215 215 1/4 215 1/2 216 216 1/4 216 1/2 217 217 1/4 217 1/2 218 218 1/4 218 1/2 219 219 1/4 219 1/2 220 220 1/4 220 1/2 221 221 1/4 221 1/2 222 222 1/4 222 1/2 223 223 1/4 223 1/2 224 224 1/4 224 1/2 225 225 1/4 225 1/2 226 226 1/4 226 1/2 227 227 1/4 227 1/2 228 228 1/4 228 1/2 229 229 1/4 229 1/2 230 230 1/4 230 1/2 231 231 1/4 231 1/2 232 232 1/4 232 1/2 233 233 1/4 233 1/2 234 234 1/4 234 1/2 235 235 1/4 235 1/2 236 236 1/4 236 1/2 237 237 1/4 237 1/2 238 238 1/4 238 1/2 239 239 1/4 239 1/2 240 240 1/4 240 1/2 241 241 1/4 241 1/2 242 242 1/4 242 1/2 243 243 1/4 243 1/2 244 244 1/4 244 1/2 245 245 1/4 245 1/2 246 246 1/4 246 1/2 247 247 1/4 247 1/2 248 248 1/4 248 1/2 249 249 1/4 249 1/2 250 250 1/4 250 1/2 251 251 1/4 251 1/2 252 252 1/4 252 1/2 253 253 1/4 253 1/2 254 254 1/4 254 1/2 255 255 1/4 255 1/2 256 256 1/4 256 1/2 257 257 1/4 257 1/2 258 258 1/4 258 1/2 259 259 1/4 259 1/2 260 260 1/4 260 1/2 261 261 1/4 261 1/2 262 262 1/4 262 1/2 263 263 1/4 263 1/2 264 264 1/4 264 1/2 265 265 1/4 265 1/2 266 266 1/4 266 1/2 267 267 1/4 267 1/2 268 268 1/4 268 1/2 269 269 1/4 269 1/2 270 270 1/4 270 1/2 271 271 1/4 271 1/2 272 272 1/4 272 1/2 273 273 1/4 273 1/2 274 274 1/4 274 1/2 275 275 1/4 275 1/2 276 276 1/4 276 1/2 277 277 1/4 277 1/2 278 278 1/4 278 1/2 279 279 1/4 279 1/2 280 280 1/4 280 1/2 281 281 1/4 281 1/2 282 282 1/4 282 1/2 283 283 1/4 283 1/2 284 284 1/4 284 1/2 285 285 1/4 285 1/2 286 286 1/4 286 1/2 287 287 1/4 287 1/2 288 288 1/4 288 1/2 289 289 1/4 289 1/2 290 290 1/4 290 1/2 291 291 1/4 291 1/2 292 292 1/4 292 1/2 293 293 1/4 293 1/2 294 294 1/4 294 1/2 295 295 1/4 295 1/2 296 296 1/4 296 1/2 297 297 1/4 297 1/2 298 298 1/4 298 1/2 299 299 1/4 299 1/2 300 300 1/4 300 1/2 301 301 1/4 301 1/2 302 302 1/4 302 1/2 303 303 1/4 303 1/2 304 304 1/4 304 1/2 305 305 1/4 305 1/2 306 306 1/4 306 1/2 307 307 1/4 307 1/2 308 308 1/4 308 1/2 309 309 1/4 309 1/2 310 310 1/4 310 1/2 311 311 1/4 311 1/2 312 312 1/4 312 1/2 313 313 1/4 313 1/2 314 314 1/4 314 1/2 315 315 1/4 315 1/2 316 316 1/4 316 1/2 317 317 1/4 317 1/2 318 318 1/4 318 1/2 319 319 1/4 319 1/2 320 320 1/4 320 1/2 321 321 1/4 321 1/2 322 322 1/4 322 1/2 323 323 1/4 323 1/2 324 324 1/4 324 1/2 325 325 1/4 325 1/2 326 326 1/4 326 1/2 327 327 1/4 327 1/2 328 328 1/4 328 1/2 329 329 1/4 329 1/2 330 330 1/4 330 1/2 331 331 1/4 331 1/2 332 332 1/4 332 1/2 333 333 1/4 333 1/2 334 334 1/4 334 1/2 335 335 1/4 335 1/2 336 336 1/4 336 1/2 337 337 1/4 337 1/2 338 338 1/4 338 1/2 339 339 1/4 339 1/2 340 340 1/4 340 1/2 341 341 1/4 341 1/2 342 342 1/4 342 1/2 343 343 1/4 343 1/2 344 344 1/4 344 1/2 345 345 1/4 345 1/2 346 346 1/4 346 1/2 347 347 1/4 347 1/2 348 348 1/4 348 1/2 349 349 1/4 349 1/2 350 350 1/4 350 1/2 351 351 1/4 351 1/2 352 352 1/4 352 1/2 353 353 1/4 353 1/2 354 354 1/4 354 1/2 355 355 1/4 355 1/2 356 356 1/4 356 1/2 357 357 1/4 357 1/2 358 358 1/4 358 1/2 359 359 1/4 359 1/2 360 360 1/4 360 1/2 361 361 1/4 361 1/2 362 362 1/4 362 1/2 363 363 1/4 363 1/2 364 364 1/4 364 1/2 365 365 1/4 365 1/2 366 366 1/4 366 1/2 367 367 1/4 367 1/2 368 368 1/4 368 1/2 369 369 1/4 369 1/2 370 370 1/4 370 1/2 371 371 1/4 371 1/2 372 372 1/4 372 1/2 373 373 1/4 373 1/2 374 374 1/4 374 1/2 375 375 1/4 375 1/2 376 376 1/4 376 1/2 377 377 1/4 377 1/2 378 378 1/4 378 1/2 379 379 1/4 379 1/2 380 380 1/4 380 1/2 381 381 1/4 381 1/2 382 382 1/4 382 1/2 383 383 1/4 383 1/2 384 384 1/4 384 1/2 385 385 1/4 385 1/2 386 386 1/4 386 1/2 387 387 1/4 387 1/2 388 388 1/4 388 1/2 389 389 1/4 389 1/2 390 390 1/4 390 1/2 391 391 1/4 391 1/2 392 392 1/4 392 1/2 393 393 1/4 393 1/2 394 394 1/4 394 1/2 395 395 1/4 395 1/2 396 396 1/4 396 1/2 397 397 1/4 397 1/2 398 398 1/4 398 1/2 399 399 1/4 399 1/2 400 400 1/4 400 1/2 401 401 1/4 401 1/2 402 402 1/4 402 1/2 403 403 1/4 403 1/2 404 404 1/4 404 1/2 405 405 1/4 405 1/2 406 406 1/4 406 1/2 407 407 1/4 407 1/2 408 408 1/4 408 1/2 409 409 1/4 409 1/2 410 410 1/4 410 1/2 411 411 1/4 411 1/2 412 412 1/4 412 1/2 413 413 1/4 413 1/2 414 414 1/4 414 1/2 415 415 1/4 415 1/2 416 416 1/4 416 1/2 417 417 1/4 417 1/2 418 418 1/4 418 1/2 419 419 1/4 419 1/2 420 420 1/4 420 1/2 421 421 1/4 421 1/2 422 422 1/4 422 1/2 423 423 1/4 423 1/2 424 424 1/4 424 1/2 425 425 1/4 425 1/2 426 426 1/4 426 1/2 427 427 1/4 427 1/2 428 428 1/4 428 1/2 429 429 1/4 429 1/2 430 430 1/4 430 1/2 431 431 1/4 431 1/2 432 432 1/4 432 1/2 433 433 1/4 433 1/2 434 434 1/4 434 1/2 435 435 1/4 435 1/2 436 436 1/4 436 1/2 437 437 1/4 437 1/2 438 438 1/4 438 1/2 439 439 1/4 439 1/2 440 440 1/4 440 1/2 441 441 1/4 441 1/2 442 442 1/4 442 1/2 443 443 1/4 443 1/2 444 444 1/4 444 1/2 445 445 1/4 445 1/2 446 446 1/4 446 1/2 447 447 1/4 447 1/2 448 448 1/4 448 1/2 449 449 1/4 449 1/2 450 450 1/4 450 1/2 451 451 1/4 451 1/2 452 452 1/4 452 1/2 453 453 1/4 453 1/2 454 454 1/4 454 1/2 455 455 1/4 455 1/2 456 456 1/4 456 1/2 457 457 1/4 457 1/2 458 458 1/4 458 1/2 459 459 1/4 459 1/2 460 460 1/4 460 1/2 461 461 1/4 461 1/2 462 462 1/4 462 1/2 463 463 1/4 463 1/2 464 464 1/4 464 1/2 465 465 1/4 465 1/2 466 466 1/4 466 1/2 467 467 1/4 467 1/2 468 468 1/4 468 1/2 469 469 1/4 469 1/2 470 470 1/4 470 1/2 471 471 1/4 471 1/2 472 472 1/4 472 1/2 473 473 1/4 473 1/2 474 474 1/4 474 1/2 475 475 1/4 475 1/2 476 476 1/4 476 1/2 477 477 1/4 477 1/2 478 478 1/4 478 1/2 479 479 1/4 479 1/2 480 480 1/4 480 1/2 481 481 1/4 481 1/2 482 482 1/4 482 1/2 483 483 1/4 483 1/2 484 484 1/4 484 1/2 485 485 1/4 485 1/2 486 486 1/4 486 1/2 487 487 1/4 487 1/2 488 488 1/4 488 1/2 489 489 1/4 489 1/2 490 490 1/4 490 1/2 491 491 1/4 491 1/2 492 492 1/4 492 1/2 493 493 1/4 493 1/2 494 494 1/4 494 1/2 495 495 1/4 495 1/2 496 496 1/4 496 1/2 497 497 1/4 497 1/2 498 498 1/4 498 1/2 499 499 1/4 499 1/2 500 500 1/4 500 1/2 501 501 1/4 501 1/2 502 502 1/4 502 1/2 503 503 1/4 503 1/2 504 504 1/4 504 1/2 505 505 1/4 505 1/2 506 506 1/4 506 1/2 507 507 1/4 507 1/2 508 508 1/4 508 1/2 509 509 1/4 509 1/2 510 510 1/4 510 1/2 511 511 1/4 511 1/2 512 512 1/4 512 1/2 513 513 1/4 513 1/2 514 514 1/4 514 1/2 515 515 1/4 515 1/2 516 516 1/4 516 1/2 517 517 1/4 517 1/2 518 518 1/4 518 1/2 519 519 1/4 519 1/2 520 520 1/4 520 1/2 521 521 1/4 521 1/2 522 522 1/4 522 1/2 523 523 1/4 523 1/2 524 524 1/4 524 1/2 525 525 1/4 525 1/2 526 526 1/4 526 1/2 527 527 1/4 527 1/2 528 528 1/4 528 1/2 529 529 1/4 529 1/2 530 530 1/4 530 1/2 531 531 1/4 531 1/2 532 532 1/4 532 1/2 533 533 1/4 533 1/2 534 534 1/4 534 1/2 535 535 1/4 535 1/2 536 536 1/4 536 1/2 537 537 1/4 537 1/2 538 538 1/4 538 1/2 539 539 1/4 539 1/2 540 540 1/4 540 1/2 541 541 1/4 541 1/2 542 542 1/4 542 1/2 543 543 1/4 543 1/2 544 544 1/4 544 1/2 545 545 1/4 545 1/2 546 546 1/4 546 1/2 547 547 1/4 547 1/2 548 548 1/4 548 1/2 549 549 1/4 549 1/2 550 550 1/4 550 1/2 551 551 1/4 551 1/2 552 552 1/4 552 1/2 553 553 1/4 553 1/2 554 554 1/4 554 1/2 555 555 1/4 555 1/2 556 556 1/4 556 1/2 557 557 1/4 557 1/2 558 558 1/4 5					








REVISIONS			
SYM	DESCRIPTION	INITIALS and DATE	
		DRAFT	CHECK
~	SEE SHEET ONE		



CURRENT VERSION - 01
PLAYFIELD GENERATOR


APPLICATION	FLYBALL
NEXT ASSY	USED ON

INTERPRET THIS DRAWING PER USASI Y14.5	DRAWN BY _____ DATE _____	<p>ATARI INCORPORATED 14600 Winchester Boulevard Los Gatos, California 95030</p>
UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES. TOLERANCES ON:	CHECKED _____	
FRACTIONS = 1/16, 1/8, 1/4, 1/2, 3/4, 1	DESIGN ENGINEER _____	
ANGLES = 1°, 5°, 10°, 15°, 30°, 45°, 60°, 90°, 120°, 135°, 180°	PROJECT ENGINEER _____	
MATERIAL _____	DOCUMENT CONTROL _____	TITLE SCHEMATIC, FLYBALL
APPROVED _____	SCALE _____	SIZE D DRAWING NO. 005629 REV A
		SHEET 3 OF 9




REVISIONS			
SYM	DESCRIPTION	INITIALS and DATE	
-	SEE SHEET ONE	DR/PTC	CHECK ENGRC

CR





CURRENT VERSION -D1
PLAYFIELD ROMS


INTERPRET THIS DRAWING PER ISIRI Y14.5	DRAWN BY	DATE	 ATARI INCORPORATED 14600 Winchester Boulevard Los Gatos, California 95030
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON	CHECKED	3-22-76	
FRACTIONS = 1/16 3/8 1/2 3/4 1 1 1/2 2 2 1/2 3 3 1/2 4 4 1/2 5 5 1/2 6 6 1/2 7 7 1/2 8 8 1/2 9 9 1/2 10 10 1/2 11 11 1/2 12 12 1/2 13 13 1/2 14 14 1/2 15 15 1/2 16 16 1/2 17 17 1/2 18 18 1/2 19 19 1/2 20 20 1/2 21 21 1/2 22 22 1/2 23 23 1/2 24 24 1/2	DESIGN ENGINEER		
ANGLES = 15° 30° 45° 60° 75° 90° 105° 120° 135° 150° 165° 180°	PROJECT ENGINEER		
SURFACE FINISH	DOCUMENT CONTROL		
MATERIAL	APPROVED		
FLYBALL			
NEXT ASSY			
USED ON			
APPLICATION			


SIZE	DRAWING NO.	REV
D	005629	A
SCALE		


SHEET 4 OF 9

















4	3	2	1
REVISIONS			
ZONE	SYM	DESCRIPTION	DATE
-	-	SEE SHEET ONE	

D

C


B


A


NOTE:

THE INFORMATION ON THIS SHEET WAS NOT REPRODUCED
BECAUSE IT COVERS CIRCUITRY THAT IS NOT OPERATOR-
REPAIRABLE.


OUTSTANDING ECNs	

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON: ANGLES = $\pm 1^\circ$ SURFACE FINISH $\sqrt{\text{xx}}$ = $\pm .03$ xxx = $\pm .010$		DO NOT SCALE DRAWING DRAWN BY: DATE 4-5-76		 ATARI INCORPORATED 14600 Winchester Boulevard Los Gatos, California 95030	
MATERIAL:		CHECKED:		TITLE	
FINISH:		ENGINEER:		SCHEMATIC, FLYBALL	
PROJECT ENGINEER:		MFG ENGINEER:		SIZE	
NEXT ASSY:		USED ON:		D	
APPLICATION:				DRAWING NO.	
				005629	
				REV	
				A	
				SCALE	
				SHEET 8 OF 9	





FLYBALL



ASSEMBLY TITLE / FLYBALL P.C. ASSY.

P/L A005629-01

PARTS LIST SPECIFICATION

Page 1 of 5

Drawn

Checked

Proj. Eng.

Mech. Eng.

Elec. Eng.

REV.
A

Rev.	Description	Date	Apprv.	Rev.	Description	Date	Apprv.
A	PROD. REL.	6/24/76					


Item	Part Number	Qty.	DESCRIPTION				
1	005630-01	1	Printed Circuit BD.				
2	10-5102	10	RES., CARBON, 5%, $\frac{1}{4}$ w, 1K				
3	10-5103	14	" " " " 10K				
4	10-5104	2	" " " " 100K				
5	10-5106	4	" " " " 10M				
6	10-5221	1	" " " " 220				
7	10-5223	2	" " " " 22K				
8	10-5824	1	" " " " 820K				
9	10-52P7	9	" " " " 2.7				
10	10-5330	1	" " " " 33				
11	10-5331	3	" " " " 330				
12	10-5471	10	" " " " 470				
13	10-5472	4	" " " " 4.7K				
14	10-5562	16	" " " " 5.6K				
15	10-5821	1	" " " " 820				
16	10-5124	1	" " " " 120K				
17	10-5154	1	" " " " 150K				
18	10-5683	1	" " " " 68K				
19	19-315252	8	TRIMPOT, 2K				
20	19-315103	1	" 10K				
21	19-315503	2	" 50K				
22	19-805W4P0	1	RES., CARBON, 5% , 10w, 4				


ASSEMBLY TITLE FLYBALL P.C. ASSY.			P/L A005629-01
PARTS LIST SPECIFICATION			REV. A
			Page 2 of 5
Item	Part Number	Qty.	DESCRIPTION
23	10-5332	1	RES., CARBON, 5%, $\frac{1}{4}$ W, 3.3K R88
24	10-5333	1	" " " " 33K R99
25	10-5473	1	" " " " 47K R96
26	21-101104	1	CAP., MYLAR, .1uf C26
27			
28	21-101472	2	" " .0047uf C34,44
29			
30			
31	24-250507	1	CAP., ELECTROLYTIC, 500uf, 25V C15
32	24-350105	4	" " 1uf, 35V C27,28,30,31
33	24-250107	1	" " 100uf,25V C49
34	24-250108	1	" " 1000uf,25V C43
35	24-250228	1	" " 2200uf,25V C42
36	24-160808	1	" " 8000uf,16V C41
37	24-250106	1	" " 10uf, 25V C48
38			
39	27-250202	1	CAP., CERAMIC DISC., .002uf,25V C54
40	27-250153	2	" " " .015uf,25V C46,47
41			
42	27-250104	55	" " " .1uf,25V C1-3,5-14,17-23,25, 29,36,40,45,50-53, 55,57-81
43	28-101050	1	CAP., DIPPED MICA, 5pf,100V C24
44	28-101221	1	" " " 220pf,100V C56
45			
46			
47	31-MCR106-1	1	SCR, MCR106 CR1
48	31-A14F	2	DIODE, A14F CR6,7
49			
50			
51	31-MR501	2	DIODE, MR501 CR4,5
52			

ASSEMBLY TITLE FLYBALL P.C. ASSY				P/L A005629-01	
PARTS LIST SPECIFICATION				REV. A	Page 3 of 5
Item	Part Number	Qty.	DESCRIPTION		
53					
54					
55	34-2N3643	1	TRANSISTOR, 2N3643	Q1	
56					
57					
58					
59	37-7400	7	I.C., 7400	B1,D3,E3,N6,L7,N7,J7	
60	37-7402	2	" 7402	R2,N8	
61	37-7403	2	" 7403	P4,M4	
62	37-7404	7	" 7404	N1,C2,B4,N4,R4,H6,P8	
63	37-7408	1	" 7408	C3	
64	37-7410	2	" 7410	P2,M7	
65	37-7420	4	" 7420	C1,B2,K6,P6	
66	37-7430	1	" 7430	J3	
67	37-7442	3	" 7442	H3,J6,M6	
68	37-7474	4	" 7474	N2,D7,P7,L1	
69					
70	37-7486	2	" 7486	A2,E7	
71	37-74109	1	" 74109	D2	
72	37-74157	2	" 74157	K3,R3	
73	37-74166	2	" 74166	E1,H1	
74	37-74175	2	" 74175	F3,K7	
75	37-74164	2	" 74164	B7,C7	
76	37-74191	8	" 74191	C4,D4,E4,F4,H4,J4,K4,L4	
77	37-74194	2	" 74194	J1,K1	
78	37-9316	6	" 9316	P1,R1,A3,B3,R6,R8	
79	37-2111A	6	" 2111A	L3,M3,N3,P3,E6,F6	
80	37-8T98	1	" 8T98	L6	
81	37-9334	1	" 9334	F7	
82	37-556	1	" 556	E8	
83	37-8T97	3	" 8T97	A4,H8,K8	
84	37-LM339	1	" LM339	L8	
85	37-741	1	" 741	D8	

ASSEMBLY TITLE FLYBALL P.C. ASSY.			P/L A005629-01	
PARTS LIST SPECIFICATION			REV. A	Page 4 of 5
Item	Part Number	Qty.	DESCRIPTION	
86	37-TDA1004	1	I.C. TDA1004	B9
87	37-MFC6040	2	" MFC6040	A8,C8
88	37-MFC3340	2 (REF)	" MFC3340	A8,C8
89	37-LM323	1	REGULATOR LM323	
90	006143-01	1	GRAPHICS	H2
91	006144-01	1 (REF)	PROGRAM HL	A5
92	006145-01	1 (REF)	PROGRAM LO	C5
93	006129-01	1 (REF)	PROGRAM ROM	D5
94	006130-01	1	" " 1000	F5
95	006131-01	1	" " 1200	H5
96	006132-01	1	" " 1400	J5
97	006133-01	1	" " 1600	K5
98	006134-01	1	" " 1800	M5
99	006135-01	1	" " 1A00	N5
100	006136-01	1	" " 1C00	R5
101	006137-01	1	" " 1E00	E2
102	006138-01	1	GRAPHICS ROM PITCHER LEFT	F2
103	006139-01	1	" " PITCHER RIGHT	J2
104	006140-01	1	" " RUNNER	K2
105	006141-01	1	" " NUMBERS	M2
106	006142-01	1	" " CHARACTER SET	L2
107			" " DIAMOND PARTS	
108				
109				
110	66-116PIT	1	SWITCH, 6 POS., DIP	SWI
111	90-6009	1	I.C.	C6
112	72-1608C	2	SCREW, PAN HD., PHIL., 6-32x1LG	CRES
113	75-016S	2	WASHER, FLAT, REG PATTERN, #6, STEEL	

ASSEMBLY TITLE FLYBALL P.C. ASSY.			P/L A005629-01	
PARTS LIST SPECIFICATION			REV. A	Page 5 of 5
Item	Part Number	Qty.	DESCRIPTION	
115	75-916C	2	NUT, HEX, #6-32, CRES	
116	78-06001	1	HEATSINK	
117	78-16005	1	SILPAD	
118	79-42524	8	24 PIN SOCKET	D5,F5,H5,J5,K5,M5,N5,R5
119	79-42540	1	40 PIN SOCKET	C6
120	90-102	1	CRYSTAL, 12.096 MHZ	Y1
121	75-056	2	WASHER, INTERNAL STAR #6	
* MFC3340 is to replace MFC6040 when stock of MFC6040 is depleted.				
**006143-01 can be installed in position H2 in place of 006139-01 thru 006142-01 in position J2 thru L2; and 006144-01 position A5 and 006145-01 position C5 can be installed in place of 006129-01 thru 006136-01 in position D5 thru P5.				





NOTES:
1. VOLTAGES VARY WITH ASSOCIATED CONTROL SETTING.
2. LINE VOLTAGE MAINTAINED AT 120V AC.
3. ALL VOLTAGES + UP AS MEASURED FROM POINT INDICATED TO
GROUND. ALL OTHER CONTROLS IN NORMAL OPERATING POSITION.
4. ALL OTHER CONTROLS IN NORMAL OPERATING POSITION.
5. UNLESS OTHERWISE SPECIFIED: CAPACITOR DECIMAL VALUE IN MF. ALL OTHERS PF. CAPACITANCE
VALUES ONLY ARE SHOWN ON SCHEMATIC DIAGRAM. FOR COMPLETE
RESISTOR VALUES SEE LIST.

MOTOROLA	
DATA	
PARTS	
CIRCUIT	
SCHEMATIC	
DRAWING	
NUMBER	
6302521A58	